


REMOTE CONTROL


SUBSCRIPTION/ ASSOCIATION / ACTIVATION AND USAGE

This user guide will explain the path that you need to follow to activate Remote Control for your car.

First of all, to use Remote Control, you need a MyDS account and register your car. If you haven't install the mobile app on your smartphone, you can easily do it by downloading the app from Google Play Store or App Store.



Open the MyDS app, visit the Services store section and select “Discover” to activate Remote Control. Tap on “START ACTIVATION” and follow the few steps to activate your new service.



You will be redirected on the Service Activation page, in which you can read what Remote Control is and what are the benefits that you will have tanks to this service. Scroll down and tap on the “GET” button to continue activating the service.


To activate Remote Control, it is important to read and accept the General Conditions and, after saving your preferences, you can start the activation process through the Mobile App, just tapping on “CONTINUE TO MYDS”.

The 3 steps that you need to follow in this moment will take you only few minutes and at the end you can start to enjoy your Remote Control. At the beginning, confirm that you have already read and accepted the terms and condition, then start the activation.

MyDS account certification process

To be able to control your vehicle remotely from your smartphone, you must complete this ten-minute path in three steps.

You can stop it at any time and resume later.




I agree to the terms and conditions of use

START

1. Enter your phone number and enter the code that you received via SMS

Close TRUSTED PHONE NUMBER < TRUSTED PHONE NUMBER < TRUSTED PHONE NUMBER



Define a trusted phone number

This telephone number will allow us to identify you in a secure way. It will be useful to ask you for confirmation of any secured operation.

Enter your trusted telephone number.

Country

Phone number

We have send you a 6-digit code by SMS. Please fill it in here to confirm your trusted phone number.

Received code

[Re-send me the code](#)


START CONTINUE CONTINUE

< TRUSTED PHONE NUMBER Close TRUSTED PHONE NUMBER

We have send you a 6-digit code by SMS. Please fill it in here to confirm your trusted phone number.

Received code

[Re-send me the code](#)




Your trusted phone number is defined!

CONTINUE

1	2 ABC	3 DEF
4 GHI	5 JKL	6 MNO
7 PQRS	8 TUV	9 WXYZ
	0	<X

CONTINUE

2. Create your personal 4-digits Safety Code. To start this step, you will receive a temporary code via SMS. First, insert it to register your phone and then create your Safety Code. This code will allow you to secure remotely access to your car and to use the Remote Control features.




3. Connect your mobile phone to your vehicle using the Bluetooth. Turn on the Bluetooth on your mobile phone, and click on "PAIR" to start the association.

MyDS account certification process

To be able to control your vehicle remotely from your smartphone, you must complete this ten-minutes path in three steps.

You can stop it at any time and resume later.



START

Secured bluetooth connection

Pick-up your car key, keep your phone with you, get on board and start the engine.

START

Make sure you are ready

- Ensure that your smartphone is connected to the internet via Wi-Fi or cellular (3G/4G).
- Turn on the engine, connect your smartphone to your car with bluetooth connexion.
[Connect my smartphone to my car](#)
- Your vehicle's privacy mode (private mode) must allow data sharing.
[Handle my car data privacy](#)

Secured bluetooth connection done

PAIR

FINISH

Now the Remote Control service is active: you might be asked to update your vehicle equipment software to full enjoy all the feature and manage your car remotely.

HOW TO USE YOUR REMOTE CONTROL:

Once you have activated Remote Control for your vehicle, you can control the locking status of your car, lock and unlock the doors or turn on the light and the horn in few simple steps.

To remotely control your car, you need only to open MyDS app, select the icon of the command that you would like to send to your vehicle, confirm the action and wait few seconds. Remember that each 7 days you need to confirm the remote commands using your safety code.

